ND-120

Electric Turntable

Instructions

Thank you for using "YVVV" "YVV"product. For your own safety, please read this user manual carefully before installing it.

Product Feature

360-Degree rotating display product or for product photography shots or video.



ND120

Standard configuration	
Turntable	1 piece
USB Cable	1 piece



Specifications

Material	Plastic	Speed	4RPM
Color	White/Black	Control	Switch
Max load capacity	2KG	Voltage	DC5V 0.5A
Rotating direction	Countercolckwise; Clockwise.		



Notes

-Damages caused by the disregard of this user manual are not subject to warranty .The dealer will not responsible for any resulting defects or problems.

-Do not overload on the turntable.

-The ambient temperature must always be between -5℃ to +45℃ Use under indoor dry condition.

-Never touch the device with wet hands, as it could lead to mortal electrical shock or injury.

-Any unauthorized modifications on the device is forbidden due to safety consideration.

-Normal noise value within 55 decibels during product operation.

Maintenance and repair

-Disconnect from mains before starting maintenance operation.

-We recommend a frequent cleaning of the device. Please use a soft lint-free dry cloth. Never use alcohol or solvents.

-Maintenance should be carried out by qualified professionals only.

-Please use the original packing for transportion in case the turntable need maintenance by manufacturer.

-Should you need any spare parts, please contact us.

Email:YVVservice@outlook.com